



Magnatone Custom M-2





Magnetone Custom M-2

Schematic redrawn by Steve Luckey on March 18, 2015




Magnatone M-2

Drawn by Steve Luckey
on 03/04/2015




Chassis = 12" x 6 1/2" x 2 1/2"




Filaments

1 1/4"


2 3/4"




NFB




V4 6GW8



V3 6GW8





V2 12AU7



V1 12AX7

1 1/4"






DRILL GUIDE

INSTRUCTIONS FOR PRINTING DRILL GUIDE

- ⊕ Turret --- drill size is 3/32"
- ⊕ Standoff – drill size to fit
- ⊕ Hole for wire pass thru – drill size to fit
- Dashed lines are underboard jumpers

Board size is 3 1/8" X 8". Print 2 copies of this drill guide FULL SIZE on letter sized paper. Use one template as a drill guide. The other template will be used for installing jumpers. Measure the board length of the printout to verify it is 8". Attach to blank board using double sided carpet tape. Use a center punch to put a mark at the cross hairs of each turret, standoff, and hole. Use a 3/32" drill bit to drill all holes. Then enlarge holes as needed for screws and wire pass thru.



Sluckey's Magnatone M2 LFO

